



TrikeTight Assembly Instructions

Pull (Red) top boom tube from the box.
Push tab in for folding the stand and unfold so boom tube is 90 degrees to front cross member.

Un fold bottom boom tube (Green) and attach the legs (don't attach wheels at this time.)
Then attach legs (Yellow). Make sure to face the legs with the angled plugs that the wheels will get bolted into with the smallest diameter facing in. Keep bolts a little loose, the uprights need to fit into the brackets.

Now attach the three uprights (blue) to the top of the legs. The top bolt gets the black two sided knobs. We like the knobs facing the rear of the bike stand but do what you like best.

You will place the rubber pinch protectors as you place the uprights in position. There is a curve to the rubber. The curve goes to the outside of the stand.

Now take the cradle and place a washer and the three sided black knob. Thread into top of upright. You can set your desired height.

Tighten all bolts now that you have the uprights, legs and booms in place. Make sure to just snug the bolts that have the knobs so the uprights move for adjustability.

The last step is to attach the wheels.
They thread in.

